



LANTE

**ATTENZIONE / CAUTIONS:**


- IT**
1. Scollegare l'alimentazione prima di effettuare qualsiasi operazione di installazione o manutenzione.
 2. L'installazione deve essere effettuata da personale qualificato secondo le norme di settore.
 3. Collegare questo dispositivo di illuminazione in base alla tensione e alle frequenze citate sul driver.
- EN**
1. Switch-off the power supply before any installation and maintenance operations.
 2. Installation should be carried out by a suitably qualified person in accordance with good electrical practice and the appropriate national wiring regulations.
 3. Connect this lighting according to voltage and frequencies mention on driver.

INSTALLAZIONE / INSTALLATION:**1**


1. Separate the base plate of the bollard.

2

2. Based on your base mounting holes, place the anchor bolts into the concrete with the right position / distancing.

3

3. Set up the AC connection, Lock the screws and fix the bollard.

4

4. Turn on the power and turn on the light to verify the installation was successful.